User Manual

# CommDTM ET 200iSP




Version: EN-012017-1.03

© Copyright 2014 - 2017 Softing Industrial Automation GmbH

## Disclaimer of liability

The information contained in these instructions corresponds to the technical status at the time of printing of it and is passed on with the best of our knowledge. The information in these instructions is in no event a basis for warranty claims or contractual agreements concerning the described products, and may especially not be deemed as warranty concerning the quality and durability pursuant to Sec. 443 German Civil Code. We reserve the right to make any alterations or improvements to these instructions without prior notice. The actual design of products may deviate from the information contained in the instructions if technical alterations and product improvements so require.

It may not, in part or in its entirety, be reproduced, copied, or transferred into electronic media.

**Softing Industrial Automation GmbH**

Richard-Reitzner-Allee 6
85540 Haar / Germany
http://industrial.softing.com

+ 49 89 4 56 56-0
+ 49 89 4 56 56-488
info.automation@softing.com
support.automation@softing.com

The latest version of this manual is available in the Softing download area at: http://industrial.softing.com/en/downloads.html

# Table of Contents

**Chapter 1 About the CommDTM ET 200iSP ..... 5**

**Chapter 2 About this manual ..... 6**

2.1 Document history ..... 6

2.2 Conventions ..... 6

**Chapter 3 FDT frame applications ..... 7**

3.1 Context menu ..... 8

3.1.1 Change device addresses ..... 8

3.1.2 Change DTM address ..... 9

3.1.3 About the CommDTM ET 200iSP ..... 10

3.1.4 Help ..... 11

**Chapter 4 Licensing ..... 12**

4.1 Licensing on PC ..... 12

4.2 Activate license ..... 12

**Chapter 5 Example of a project design ..... 14**

5.1 Prerequisites ..... 14

5.2 FDT frame application ..... 14

5.3 Add CommDTM PROFIBUS DP-V1 ..... 15

5.4 Add CommDTM ET 200iSP ..... 15

5.5 Add HART device DTM ..... 16

**Chapter 6 Establish and disconnect device online connection ..... 18**

This page is intentionally left blank.


Copyright 2017 Softing Industrial Automation GmbH

# 1 About the CommDTM ET 200iSP

The SIMATIC® ET 200iSP Remote I/O, frequently used in process control plants, is an essential structural element for the connection of HART devices to PROFIBUS. The respective CommDTM ET 200iSP can be implemented into all FDT frame applications according to FDT Specification 1.2 + Addendum. In this role the DTM acts as a device driver enabling DP-V1 communication with HART devices at ET 200iSP peripheral devices and their Device DTMs.

The CommDTM ET 200iSP considerably facilitates configuration, parameterization and calibration, as well as commissioning, diagnosis and maintenance of field devices. You can use the CommDTM ET 200iSP within one FDT frame application repeatedly and concurrently (depending on the available ET 200iSP in the PROFIBUS network). To do so, load the CommDTM ET 200iSP repeatedly into the project window. For the PROFIBUS DP-V1 communication, a respective physical access to the PROFIBUS and a respective CommDTM PROFIBUS DPV1 needs to be available. You can use the CommDTM PROFIBUS DP-V1 with the TH LINK PROFIBUS hardware.

The CommDTM ET 200iSP is protected with a software key. You need to license the software for unlimited use (see Licensing) 12. CommDTM ET 200iSP functionalities can be accessed through the context menu of the used FDT frame application.




Figure 1: Example of a PROFIBUS network with several ET 200iSP

# 2 About this manual

**Read this manual before starting**

For damages due to improper connection, implementation or operation Softing refuses any liability according to our existing guarantee obligations.

## 2.1 Document history

| Document version | Modifications compared to previous version |
|---|---|
| 1.00 | none |
| 1.01 | ▪ License Manager version added.<br>▪ Licensing procedure updated. |
| 1.02 | New Corporate Identity implemented. |
| 1.03 | Minor changes and corrections incl. product name change from "xEPI 2" to "TH LINK PROFIBUS". |

## 2.2 Conventions

The following conventions are used throughout Softing customer documentation:

| | |
|---|---|
| Keys, buttons, menu items, commands and other elements involving user interaction are set in bold font and menu sequences are separated by an arrow | Open **Start** → **Control Panel** → **Programs** |
| Buttons from the user interface are enclosed in brackets and set to bold typeface | Press **[Start]** to start the application |
| Coding samples, file extracts and screen output is set in Courier font type | `MaxDlsapAddressSupported=23` |
| Filenames and directories are written in italic | Device description files are located in *C:\<product name>\delivery\software\Device Description files* |

**CAUTION**

CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

**Note**

This symbol is used to call attention to notable information that should be followed during installation, use, or servicing of this device.

**Hint**

This symbol is used when providing you with helpful user hints.


Copyright 2017 Softing Industrial Automation GmbH

# 3 FDT frame applications

The different FDT frame applications vary in functionality and naming of the individual functions. In this User Manual the naming refers to the »FieldCare« frame application. Complete functionality for the frame application is described in the FieldCare online help.




Figure 2: FieldCare

## 3.1 Context menu

Right-click an entry in the project window of the FDT frame application to open the context menu. Its entries are default entries of the FDT frame application. Select **Additional functions** in this window to display the entries to the respective DTM. Functionalities displayed in gray are not supported or already opened. To select these functions, an online connection might be required.

Integration of CommDTM ET 200iSP into a project is described in Section Example of a project design 14.




Figure 3: Context menu for the CommDTM ET 200iSP

### 3.1.1 Change device addresses

Using this function you can display and change the address of the field devices that are connected to the ET 200iSP. This function is only available online. You can only modify the address of field devices support by this function.




Figure 4: Modify device address


Copyright 2017 Softing Industrial Automation GmbH

Proceed as follows:

1. Right-click **CommDTM ET 200iSP** in the project window and select the function **Establish connection**. The existing online connection is displayed in the FDT frame application (see Help for »FDT Frame Application«).
2. Right-click **CommDTM ET 200iSP** in the project window and select the function **Additional functions → Change device addresses**.
3. Select the **channel** in the selection field and click **[Refresh]**. The field devices appear in the window **Change device addresses**. Corresponding device names, DTM vendors and DTM versions are displayed only if a DTM is installed for the field device concerned.
4. Select the field device.
5. Select a new address from the list box **Current device address** in the lower window and click **[Accept]**. An online connection to the field device is automatically established, the address is modified, and the field device is disconnected again. In the status bar of the window, information is displayed on whether this function has been completed successfully, or whether the field device does not support this functionality.

**Note**

After changing the device address you need to set the DTM address of the respective device DTM to the identical address.

**Note**

Not all devices support device address setting through the CommDTM ET 200iSP. Device addresses for some field devices can only be set directly at the field device. Refer to the manual of the respective field device vendor for detailed information.

### 3.1.2 Change DTM address

Using this function you can display and change the DTM addresses of the field device DTMs. This function is only available offline. Make sure to use an identical address both for the field device and for its respective DTM. The DTM address displayed or set is used during connection establishment to the respective field device.




Figure 5: Change DTM address

Proceed as follows:

1. Right-click **CommDTM ET 200iSP** in the project window and select the function **Additional functions → Change DTM addresses**.

2. Click **[Refresh]** to start scanning.
3. The DTM addresses are now listed in the window **Change DTM addresses**. Corresponding device names, DTM vendors and DTM versions can only be displayed if this functionality is supported by the frame applications.
4. Mark the DTM.
5. Select a new address for the field device DTM from the list box **Current device address** in the lower window part and click **[Accept]**. In the status bar of the window, information is displayed on whether this function has been completed successfully, or whether the DTM does not support this functionality.

**Note**

This function is not supported by all DTMs. You can only change the DTM address directly through the field device DTM in the project.

### 3.1.3 About the CommDTM ET 200iSP

This functionality displays information about the installed CommDTM ET 200iSP.




Figure 6: About CommDTM ET 200iSP

Proceed as follows to open this window:

1. In the project window right-click on **CommDTM ET 200iSP**.
2. Select **Additional functions → About CommDTM ET 200iSP**. Information about CommDTM ET 200iSP are displayed.


Copyright 2017 Softing Industrial Automation GmbH

### 3.1.4 Help

In the context menu select **Additional functions → Help**. This function opens the User Manual in PDF format. Adobe Acrobat Reader is required. The User Manual is available after installing the DTM library locally on your system.




Figure 7: User Manual

# 4 Licensing

CommDTM ET 200iSP is protected with a software key. You need to license the software for unlimited use.

**30-days demo license**

Please contact our support to use the CommDTM ET 200iSP with a 30-day trial license. Thus you obtain a test license key allowing you to use CommDTM ET 200iSP up to 30 days with complete functionality after activation. After expiry of the 30-days-demo version you will no longer be able to establish an online connection. Online connections existing at the time of expiration will be terminated.

**License state**

The license is generated for the current system only. A transfer to another system is not possible. You can find the current license state in the **About CommDTM ET 200iSP** window (context menu: → **Additional functions** → **About CommDTM ET 200iSP**).

**Automatic licensing with Endress+Hauser frame application**

If you are using an Endress+Hauser frame application, CommDTM ET 200iSP is automatically licensed and activated and you can skip the following sections.

## 4.1 Licensing on PC

The licensing on PC consists of a runtime license which activates the complete software functionality on a PC.

## 4.2 Activate license

**Online help**

The License Manager includes an online help which gives you detailed information about the licensing procedure and helps you to solve possible problems. Click in the left part of the License Manager user interface on **[Help]** and select the corresponding topic.

### Activate license on PC - with internet access

1. Start the License Manager V4 with **Start** → **All Programs** → **Softing** → **License Manager** → **License Manager V4**.
2. Select **Activate for this PC**.
3. Enter the license key in the following format XXXXX-XXXXX-XXXXX-XXXXX into the field **License Key**.
4. Click **[Activate license]**.
5. After a successful activation your license is displayed in the field **Available licenses on this PC**.

### Activate license on PC - without internet access

1. Start the License Manager V4 on the PC where you want to use the license. Select **Start** → **All Programs** → **Softing License Manager** → **License Manager V4**.
2. Select **Activate for this PC**.


Copyright 2017 Softing Industrial Automation GmbH

3. Click **Export PC-IDs...**
4. Select your PC and click **[OK]** in order to save the file.
5. Transfer this file to a PC with internet access and License Manager installed in the current version.
6. Start License Manager V4 on this PC. Switch to **Generate license file for remote PC**. Enter the license key. Click **Import PC-Id from remote PC**.
7. Select **Generate and export license file...** .
8. Save this file and transfer the file to the original PC.
9. Select **Activate for this PC**.
10. Click **[Import license file]** and import the file.
11. Then click **[Activate license]**.
12. After a successful activation your license is displayed in the field **Available licenses on this PC**.

Copyright 2017 Softing Industrial Automation GmbH

# 5 Example of a project design

The CommDTM ET 200iSP allows to access HART field devices. HART field devices do not have a PROFIBUS address. Every device is operated through one channel of the HART modules of the ET 200M. The PROFIBUS communicates acyclically via a MCL2 configuration master. For communication with field devices, the respective field device DTM needs to be integrated into the project of the FDT frame application. Via this integration, the field deviceDTM is assigned to the respective HART module channel of the ET 200iSP.




Figure 8: Communication principle to field devices

## 5.1 Prerequisites

The following software must be installed:

- FDT frame application
- Softing DTM Library
- HART field device DTM

## 5.2 FDT frame application

1. Start the FDT frame application.
2. Open and update the device catalog.
3. Create a new project.


Copyright 2017 Softing Industrial Automation GmbH

## 5.3 Add CommDTM PROFIBUS DP-V1

1. In the project window right-click **Host PC** and select **Add device**.
2. From the device catalog select CommDTM PROFIBUS DP-V1 and click **[OK]**.
3. Configure the CommDTM PROFIBUS DP-V1. To do so open the CommDTM PROFIBUS DP- V1 context menu and select **Configuration**. You can find more information in the User Manual for CommDTM PROFIBUS DP-V1.




Figure 9: Added CommDTM PROFIBUS DP-V1

## 5.4 Add CommDTM ET 200iSP

1. In the project window right-click **CommDTM PROFIBUS DP-V1** and select **Add device**.
2. From the device catalog select CommDTM ET 200iSP and click **[OK]**.
3. The window for setting DTM addresses is opened:




Figure 10: Set DTM address

4. Set the DTM address and then click **[OK]**.




Figure 11: Added CommDTM ET 200iSP

## 5.5 Add HART device DTM

1. You can connect up to 128 HART field devices to a ET 200iSP. Likewise you can integrate up to 128 HART field device DTMs into the project.
2. Right-click **CommDTM ET 200iSP → Add device**.
3. From the device catalog select the device DTM and click **[OK]**. The window for selecting the slot and the corresponding channel appears:

Figure 12: Select channel

4. Select the slot with the respective channel for the HART field device (numeration of slots/channels see Siemens documentation for ET 200iSP). Click **[OK]**.


Copyright 2017 Softing Industrial Automation GmbH




Figure 13: Added field device DTM

5. Establish an online connection (refer to Establish and disconnect an online connection [18]).

**Note**

You cannot modify the selected slot and the channel number for a HART field device DTM afterwards. If you do have to change the slot or channel number, remove the DTM from the project via context menu and then reinsert the DTM again.

# 6 Establish and disconnect device online connection

## Establish an online connection

1. Establish an online connection to the device. Right-click on an entry in the project window and select the function **Establish connection**. The existing online connection is displayed in the FDT frame application (see Help for »FDT Frame Application«). All superordinated components are connected as well.
2. Depending on the selected device, you can now read out the configuration, or write the configuration set in the FDT frame application to the device. To do so, use the respective function in the context menu.

## Disconnect an online connection

1. To disconnect the online connection right-click the desired entry in the project window. Select the function **Go offline**.
2. The connection of the selected device is disconnected. Existing connections from other devices are maintained.

**Note**

You need to establish a connection for each field device. You can terminate the connection for each single field device. The connection is established and terminated via the context menu of the respective field device DTM.

If you terminate the connection to the CommDTM ET 200iSP or to the CommDTM PROFIBUS DP-V1, all online connections to the field devices are terminated automatically.


Copyright 2017 Softing Industrial Automation GmbH

This page is intentionally left blank.

**Softing Industrial Automation GmbH**

Richard-Reitzner-Allee 6
85540 Haar / Germany
http://industrial.softing.com

Tel: + 49 89 45 656-0
Fax: + 49 89 45 656-488
info.automation@softing.com