

**Release Notes** 

# pnGate DP/PA/PB

# Version 1.30

March 2020

Softing Industrial Automation GmbH Richard-Reitzner-Allee 6 D-85540 Haar Tel.: +49 89 4 56 56-340 Fax: +49 89 4 56 56-488 <u>info.idn@softing.com</u> http://industrial.softing.com



## **1** Components of Current Product Version

Component	Files	Version
Firmware pnGate DP/PA/PB	Firmware.bin	1.30

### 2 Product Documentation

Title	Version
User Guide pnGate DP/PA/PB	March 2020

#### **3** Scope of Release

With this release the following components and documents are made available for download from the product page at <a href="https://industrial.softing.com/en/downloads.html">https://industrial.softing.com/en/downloads.html</a>.

#### 4 New and Changed functions

#### New functions

- New Hardware: pnGate DP
- S2 Redundancy
- Configuration in Run
- pnGate DP/PA/PB now certified by PI
- Improved usability of GSDML

(replacement of FAP-modules, support GAP's between subslots)

#### **Changed functions**

None.

#### 5 Bug fixes

- #150 interrupted HTTPS connection during FW-Update, erasing of configuration
- #159 HTTPS request not responded
- #235 wrong <IOData> section in generated GSDML